

Wall tile laying vibrator

Product Manual



Patented product. Counterfeiting not allowed.


Lithium Electric Tile laying vibrator



[Type] V07
[Suitable range] 30-100cm Ceramic tile
[Product weight] 2.64kg
[Product function] For sticking wall bricks and floor tiles.
[Vibration frequency] 12000r/min



[Type] V-08
[Suitable range] 30-60cm Ceramic tile
[Product weight] 2.45kg
[Product function] For sticking wall bricks and floor tiles.
[Vibration frequency] 10000r/min



[Type] V10-1 (V10-2)
[Suitable range] 30-120cm Ceramic tile
[Product weight] 3.6kg(3.86kg)
[Product function] For sticking wall bricks and floor tiles.
[Vibration frequency] 21000r/min



[Type] V-11
[Suitable range] 30-180cm Ceramic tile
[Product weight] 4.2kg
[Product function] For sticking wall bricks and floor tiles.
[Vibration frequency] 23000r/min

Usage Instruction

1. Place the tile at certain position, place the machine on the tile.
2. Touch the micro switch on the left head of the machine. When the machine starts to work, glue the protruding part of the tile instantly.
3. The frequency of vibration can be adjusted by speed regulating switch.

Charging Instructions

1. After receiving the product, please charge it and use it after it is full.
 2. When charging, please insert the rear power plug into the base socket, and insert the plug into the power socket. Then the charging light will be on.
 3. Normal charging time: 3-4 hours (stops when fully charge - the light turns green or not bright).
 4. Product working time: more than 6-8 hours after fully charged. In order not to affect the service life of the product, please be sure to charge it every day during normal use.
 5. When using the product normally, please charge it once a day; when not in use, charge it every half a month.
- Remove the battery if it has not been used for a long time.
6. It is forbidden to charge for a long time to avoid spontaneous combustion.

Attention

1. No-load operation is not allowed.
2. The machine should be stored in a dry place to avoid liquid.
3. Please timely remove the dust on the suction cup.
4. Please do not disassemble the machine. Our company is not responsible for any consequence of the disassembling.
5. Minors are strictly prohibited to use, in order to avoid danger.

After-sales Service

1. The whole machine is guaranteed for three months.
2. For any problem after the warranty period, maintenance fee is free. Only the cost of the machine parts will be charged.
3. The company is not responsible for the damage caused by personal reasons or the loss caused by disassembling or repairing.
4. For anything wrong with the machine, please dial the after-sale telephone in time.

Notes on Exchange

1. Notes on Exchange
Exchange due to quality problems - round-trip freight borne by us. Exchange due to non-quality problems - round-trip freight borne by the buyer. Quality problem is defined as damaged or incomplete.
If the goods are damaged in the logistics process, our company is not responsible for the round-trip freight of goods under. When signing for the delivery, please check whether the parcel has any marks of being open, and whether it is damaged or wet from the outer of the product.
Should any of these happens, please do not sign for the goods. Please contact logistics for compensation.
2. Attention
To customers who come to pick up the goods: for any quality problem, if you need to exchange the goods, we are not responsible for the round-trip freight. The goods to be exchanged must be kept not to affect the second sale.
For the defective gift, which is not the quality problem of the goods itself and does not affect the use of the main goods, the gift cannot be exchanged.
If there is any quality problem due to abnormal use by the user, it shall not be returned or exchanged.